

STRING INSTRUCTIONS:

①

- ① Used for moving large blocks of data.
- ② For all string instructions, the memory source is DS:SI & memory destination is ES:DI.
- ③ The offset memory pointers, SI & DI, are automatically incremented or decremented on the state of DF \rightarrow by 1 for bytes or by 2 for words.

STOSB \rightarrow ES:[DI] \leftarrow AL
If DF = 0, DI \leftarrow DI + 1
If DF = 1, DI \leftarrow DI - 1

STOSW \rightarrow ES:[DI] \leftarrow AX
ES:[DI+1] \leftarrow AH
If DF = 0, DI \leftarrow DI + 2
If DF = 1, DI \leftarrow DI - 2

Explanation: Transfer a byte (STOSB) or word (STOSW) from register AL or AX to the string element addressed by DI in the extra segment. If Direction Flag (DF = 0) \rightarrow increment DI, else decrement DI. Flags are not affected.

